





Packing List 配件清单



For the safety of your operation, it's strictly prohibited to remove this sticker on the Control Board when using a non-CONSPIT wheel with QR communication functionality. 为了您方向盛的使用安全,使用带快拆通信的非CONSPIT 方向盘时停车辆下电路板上的贴纸。

CDR quick release (wheelbase-side) CDR 快拆 (基座端)



wheelbase shaft fixing rope 基座轴固定绳



hex wrench 3.0, 2.0, 1.5 内六角扳手 3.0, 2.0, 1.5



M5*30mm (6 ×)

M5*30mm $(6 \times)$ M3*6mm $(2 \times)$ Pull out and plug in 穿出并接入PCB The base shaft can be secured by using the fixing rope and the adjacent bracket mounting holes, so as to prevent it from rotating while bolts are being tightened. 可使用基座轴固定绳 及附近的支架固定孔 来固定基座轴,防止其 在拧螺丝时发牛旋转。

安装前需拆下PCB(编号@处)

The PCB needs to be removed before installation (at mark 3).

1 -