

Connected Devices


PW1

Conspit Link 2.0 PW1 Tutorial





Please read this tutorial in full before first use!

One-Click Game Configuration




- | | | |
|------|------------------------------|-----|
| I | Homepage | P02 |
| II | Configs | P07 |
| III | Basic Settings | P10 |
| IV | Dashboard Settings | P31 |
| V | Paddles Settings | P37 |
| VI | Firmware Update | P43 |
| VII | One-Click Game Configuration | P47 |
| VIII | Games' Telemetry List | P50 |





Connected Devices

 PW1

I Home Page



One-Click Game Configuration

SIMULATION SEAT ULTIMATE
EXPERIENCE

GT-Lite



Plugins



Overlay

1. Click to enter the Homepage.

Connected Devices

PW1

CONSPIT

One-Click Game Configuration

SIMULATION SEAT ULTIMATE
EXPERIENCE

GT-Lite



Plugins



Overlay



Connected Devices



PW1

2. Click to select PW1.



One-Click Game Configuration

SIMULATION SEAT ULTIMATE
EXPERIENCE


GT-Lite



Plugins



Overlay









Connected Devices



 PW1



On the right side of the homepage, you can quickly adjust the light brightness of the device, and check the clutch paddles' travel.

Global Brightness


Button  

Rev Lights  

Indicators  

Dashboard  

Clutch Mode

Manual 

0%



Left 0%

Right 0%

One-Click Game Configuration


At the bottom of the home page, you can activate the plugin to monitor the inputs of the pedals and steering wheel in real-time through a floating window.

Plugins




Overlay






Connected Devices

 PW1

3. Double-click the device name in the "Connected Devices" list, or click the corresponding icon of the device to enter the detailed settings pages.



Global Brightness



Rev Lights



Indicators




Dashboard



Clutch Mode

Manual



One-Click Game Configuration

SIMULATION SEAT ULTIMATE
EXPERIENCE


GT-Lite



Plugins



Overlay



PW1



0.0.2 beta 1

Configs



Default



Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

II Configs



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators



Dashboard



Reset

Save As

Save to Flash



07/51





PW1

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators



1. In each setting page, in the "Config" section at the bottom left, you can select, rename, add, export, import, or delete configs.

Configs



Default



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators



Dashboard




Reset


Save As

Save to Flash



08/51





PW1

Default

Configuration

Dashboard


Paddles

Global

Button

Rev Lights

Indicators



2. If you need to customize the settings, please create a new config, click "Save" after setting is completed, or modify the official default config and click "Save as".

Configs



Default



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators



Dashboard



Reset

另存为

Save to Flash



09/51





Default

Configuration

Dashboard

Paddles



0.0.2 beta 1


Configs



Default



III Basic Settings



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators



Dashboard



Reset

Save As

Save to Flash



10/51



1. Click on "Configuration" in the menu bar to enter the lights & buttons settings interface.

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

0.0.2 beta 1

Configs

Default

Boot Animation

Rev Lights Mode

Bind to Left Toggle Switch

Generic Mode

Global Brightness

Button

Rev Lights

Indicators


Dashboard

Reset

Save As

Save to Flash

11/51



1.1 Click on "Global".

Default
Global

Configuration

Dashboard

Paddles

Button

Rev Lights

Indicators



0.0.2 beta 1

Configs



Default



Boot Animation



Rev Lights Mode

Generic Mode

Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators




Dashboard



Reset

Save As

Save to Flash



PW1

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators



0.0.2 beta 1

Configs



Default



Set the Boot Animation and the Rev Lights mode here. Changing the Rev Lights mode will affect the number of Rev lights and indicator lights. You can bind the toggle of Rev Lights Mode to the Left Toggle Switch.

Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch

Generic Mode

Formula Mode

Global Brightness

Button



Rev Lights



Indicators



Dashboard



Reset

Save As

Save to Flash



13/51





PW1

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators



0.0.2 beta 1

Configs



Default



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch

Generic Mode

Formula Mode

Global Brightness

Button	<input type="range"/>	
Rev Lights	<input type="range"/>	
Indicators	<input type="range"/>	
Dashboard	<input type="range"/>	

Adjust the brightness of the lights and screen in the "Global Brightness" section.


Reset

Save As

Save to Flash



14/51





PW1

1.2 Click on "Button".

Default

Global

Button

Rev Lights

Indicators

Configuration

Dashboard

Paddles



0.0.2 beta 1

预设



Default



Boot Animation



Rev Lights Mode

Generic Mode



Bind to Left Toggle Switch



Global Brightness

Button



Rev Lights



Indicators



Dashboard



Reset

Save As

Save to Flash




15/51



Set the Global Button Lights (which overrides the current settings for individual lights), preview activated colors, and configure the Button Lights Mode here. (Global Color is not available while in "Telemetry Mode".)

Button Lights Global Setting

Global Color 

Activated Preview ☐

Button Lights Mode Button Mode ▾

*Telemetry Mode: Button Lights light up by game telemetry
*Button Mode: Button Lights light up when pressed

- * Telemetry Mode: Button RGBs light up by game telemetry
- * Button Mode: Button RGBs light up when pressed

Reset

Save As

Save to Flash



PW1

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators



#2



#3



#5



#4



#6

Click to set color or functions.
Choose "#1" and select.

*Click on the Light to set color

0.0.2 beta 3

Button Lights Global Setting

Configs



Default



Global Color



Activated Preview



Button Lights Mode

Buttom Mode



*Telemetry Mode: Button Lights light up by game telemetry

*Button Mode: Button Lights light up when pressed

Reset

Save As

Save to Flash



17/51




Global

Button

Rev Lights

Indicators



#

#3

#4

#5

#6

When the Button Lights Mode is set to "Telemetry Mode", choose your preferred color here.

Configs

Default

Global Color

Activated Preview

Button Lights Mode

Button Mode

*Telemetry Mode: Button Lights light up by game telemetry

*Button Mode: Button Lights light up when pressed

When the Button Lights Mode is set to "Telemetry Mode", After selecting the "RGB #1" you can enable and set the functions for "RGB #1" here. The settings here determine the color that the button light will automatically illuminate when the selected function is triggered within the game.

RGB #1 Configuration ☐

Function Setting

Activated Color

Always On

DRS Available

DRS Available

DRS Activated

ABS

TC

Wheel Lock

Wheel Slip

Telemetry Mode

Telemetry Mode

Button Mode



0.0.2 beta 3

Configs



Default

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

#1

#2

#3

#5

#6

#4

*Click on the Light to set functions

Button Lights Global Setting

Global Color

Activated Preview

Button Lights Mode

Telemetry Mode

*Telemetry Mode: Button Lights light up by game telemetry
*Button Mode: Button Lights light up when pressed

RGB #1 Configuration

Function Setting

Activated Color

Always On



DRS Available

Flashing

1.3 Click on Rev Lights.

Reset

Save As

Save to Flash



PW1

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

Click to set color.
Choose a Rev light and select.



0.0.1 beta 2

Configs



Default



Rev Lights Setting

Quick Setting

Lighting Preview



Blink Color



Blink Interval

200

ms

Manual

First Shift Light

4500

RPM

Last Shift Light

7000

RPM

Blink RPM

7500

RPM

Auto (detect current car's max RPM)



First Shift Light



0

Last Shift Light



0

Use Game Shift RPM



Reset

Save As

Save to Flash



21/51





PW1

Default

Configuration

Dashboard

Paddles


Global

Button

Rev Lights

Indicators

Choose your preferred color.



0.0.1 beta 2

Configs



Default



Rev Lights Setting

Lighting Preview



Blink Color



Blink Interval 200 ms

Manual

First Shift Light 4500 RPM

Last Shift Light 7000 RPM

Blink RPM 7500 RPM

Quick Setting

Auto (detect current car's max RPM)



First Shift Light



0

Last Shift Light



0

Use Game Shift RPM



Reset

Save As

Save to Flash



22/51



Preview the lights here, set the Blink Color and Interval, and choose to manually input the Rev light parameters, or enable "Auto" and configure the Rev light percentage. You can also opt to turn on the Game Shift RPM to directly read the RPM data of the race car within the game.

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

Rev Lights Setting

Quick Setting

Lighting Preview

Blink Color

Blink Interval

200

ms

First Shift Light

4500

RPM

Last Shift Light

7000

RPM

Blink RPM

7500

RPM

Auto (detect current car's max RPM)

First Shift Light

0

Last Shift Light

0


Use Game Shift RPM

Reset

Save As

Save to Flash

23/51



PW1



0.0.1 beta 2

Configs



Default



Default

Configuration

Dashboard

Paddles


Global

Button

Rev Lights

Indicators

1.4 Click on "Indicators".



Rev Lights Setting

Quick Setting

Lighting Preview



Auto (detect current car's max RPM)



Blink Color



Blink Interval

200

ms

First Shift Light



0

Manual

First Shift Light

4500

RPM

Last Shift Light



0

Last Shift Light

7000

RPM

Use Game Shift RPM



Blink RPM

7500

RPM

Reset

Save As

Save to Flash



24/51





PW1

Default

Configuration

Dashboard

Paddles

Global


Button

Dev Lights

Indicators

* If the Button RGBs Mode is set to "Formula Mode" on page 13, then the 5 lights on the left side will function as indicator lights.

Click to set color.
Choose "#1" and select.



#1



#2



#3



#4

#5

#6

0.0.1 beta 2

Configs



Default



Indicators #1 Function Setting

DRS Available



DRS Activated



ABS



TC



Color



Color



Color



Color



Light Mode

Flashing



Light Mode

Flashing



Light Mode

Flashing



Light Mode

Flashing



Lighting Preview

DRS Available



DRS Activated



ABS



TC



Reset

Save As

Save to Flash



25/51



Set the function for the indicator light "#1" here.

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

#1

#2

#3

#4

#5

#6

Indicators #1 Function Setting

DRS Available



DRS Activated



ABS



TC



Color



Color



Color



Color



Light Mode Flashing



Light Mode Flashing



Light Mode Flashing



Light Mode Flashing



Lighting Preview

DRS Available



DRS Activated



ABS



TC



Reset

Save As

Save to Flash



Select the function
you want to enable
for indicator light
"#1".

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

- #1
- #2
- #3

- #4
- #5
- #6

Indicators #1 Function Setting

DRS Available	<input checked="" type="checkbox"/>	DRS Activated	<input checked="" type="checkbox"/>	ABS	<input checked="" type="checkbox"/>	TC	<input checked="" type="checkbox"/>
Color	<div></div>	Color	<div></div>	Color	<div></div>	Color	<div></div>
Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing

Lighting Preview

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
---------------	--------------------------	---------------	--------------------------	-----	--------------------------	----	--------------------------

Reset

Save As

Save to Flash



PW1

0.0.1 beta 2

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

#1

#2

#3

#4

#5

#6

Indicators #1 Function Setting

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
Color	<input type="color" value="red"/>	Color	<input type="color" value="red"/>	Color	<input type="color" value="red"/>	Color	<input type="color" value="red"/>
Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing

Lighting Preview

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
---------------	--------------------------	---------------	--------------------------	-----	--------------------------	----	--------------------------

Reset

Save As

Save to Flash



PW1



0.0.1 beta 2

Configs



Default

Select Light Modes.

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators



#1



#2



#3



#4



#5



#6



Indicators #1 Function Setting

DRS Available	<input checked="" type="checkbox"/>	DRS Activated	<input checked="" type="checkbox"/>	ABS	<input checked="" type="checkbox"/>	TC	<input checked="" type="checkbox"/>
Color	<div></div>	Color	<div></div>	Color	<div></div>	Color	<div></div>
Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing

Lighting Preview

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
---------------	--------------------------	---------------	--------------------------	-----	--------------------------	----	--------------------------



Reset

Save As

Save to Flash



In "Lighting Preview",
when any function is
activated, you can check
the display of lighting
set for all indicators.
To edit again, deactivate
the items in "Lighting
Preview".

0.0.1 beta 2

Configs

Default

Default

Configuration

Dashboard

Paddles

Global

Button

Rev Lights

Indicators

Indicators #1 Function Setting

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
Color	<div></div>	Color	<div></div>	Color	<div></div>	Color	<div></div>
Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing

Lighting Preview

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
---------------	--------------------------	---------------	--------------------------	-----	--------------------------	----	--------------------------

Reset Save As Save to Flash



PW1

Default

Configuration

Dashboard

Paddles



IV Dashboard Settings

Global Button Rev Lights Indicators

#1
#2
#3



#4
#5
#6



0.0.1 beta 2

Configs



Default

Indicators #1 Function Setting

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
Color	<div></div>	Color	<div></div>	Color	<div></div>	Color	<div></div>
Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing	Light Mode	Flashing

Lighting Preview

DRS Available	<input type="checkbox"/>	DRS Activated	<input type="checkbox"/>	ABS	<input type="checkbox"/>	TC	<input type="checkbox"/>
---------------	--------------------------	---------------	--------------------------	-----	--------------------------	----	--------------------------



Reset

Save As

Save to Flash

1. Click on "Dashboard" in the menu bar to enter the dashboard settings interface.



Global

Button

Rev Lights

Indicators

#1

#2

#3

#4

#5

#6

Indicators #1 Function Setting

DRS Available



Color



Light Mode

Flashing



DRS Activated



Color



Light Mode

Flashing



ABS



Color



Light Mode

Flashing



TC



Color



Light Mode

Flashing



Lighting Preview

DRS Available



DRS Activated



ABS



TC



Reset

Save As

Save to Flash



32/51





0.0.1 beta 2

Default

Configuration

Dashboard

Paddles

Dashboard Playlist

Preview

1

2

3

4

5

6

7

8

9

10

11

12

How to set?

1. Preview: Click any dashboard to display the detail.
2. Dashboard Playlist: Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
3. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

2. "All Dashboards" displays the currently available dashboard styles.
Preview: Click to select a dashboard to display.

All Dashboards

00:49.030

P02 080.0

LAP 7

FL 7.0

F 48.0

DRS

DT

5

240

00:48.210

1

5

75

80

1.34

1.34

1.34

1.34

00:48.030

P02 080.0

LAP 7

FL 7.0

F 48.0

DRS

DT

5

240

00:48.210

1

5

75

80

1.34

1.34

1.34

1.34

12

2

3

6

N

22.5

22.5

22.5

22.5

90

22.5

22.5

12

2

3

6

N

22.5

22.5

22.5

22.5

90

22.5

22.5

345

20.2

51.40

00:02.4331

01:46.1991

3

3

1

1

6

3

3

1

1

6

51.4

00:02.4331

01:46.1991

13.4

77

206

00:02.433

38.7

191

3

3

1

1

6

123

00:02.433

11.45

1

00:02.433

+1.500

1

1

4

1

5

51.0

4

170

57.77

11.45

N

55.71

12.10

1

1

4

5

1.00

4

Preview the dashboard style here.



0.0.1 beta 2

Configs

Default

1

2

3

4

5

6

7

8

9

10

11

12

Preview

00:49.030

P02 080.0°

LAP 7

FL 7.0

F 46.0

DRS

OT

5

240

00:48.210

00:50.120

+1.01

MAP 1

MODE 5

DIFF 75

BIAS 60

1.91 1.94

25.11 25.11

1.93 1.95

25.11 85

- How to set?
1. Preview: Click any dashboard to display the detail.
 2. Dashboard Playlist: Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
 3. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

All Dashboards

00:49.030

P02 080.0°

LAP 7

FL 7.0

F 46.0

DRS

OT

5

240

00:48.210

00:50.120

+1.01

MAP 1

MODE 5

DIFF 75

BIAS 60

1.91 1.94

25.11 25.11

1.93 1.95

25.11 85

00:48.030

P02 080.0°

LAP 7

FL 7.0

F 46.0

DRS

OT

5

240

00:48.210

00:50.120

+0.00

MAP 1

MODE 5

DIFF 75

BIAS 60

1.91 1.94

25.11 25.11

1.93 1.95

25.11 85

12

2

3

6

N

90

22.5

22.5

12

2

3

6

N

90

22.5

22.5

345 20.2

51.40

202.0 19.40

3

3

1

1

6

34.6 10.00

00:02.4331

01:46.1991

3

3

1

1

6

3

51.4

N

3

3

1

1

6

3

51.4

N

3

3

1

1

6

3. Dashboard Playlist:
Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
Rotate the rotary switch knob in the center of the steering wheel to switch the dashboard display ↓:



Dashboard Playlist

1	2	3
4	5	6
7	8	9
10	11	12

Preview

00:49.030	5	+1.01	
P02 080.0°		MAP	1
LAP 7		MODE	5
FL 7.0		DIFF	75
F 46.0		BIAS	60
DRS	240	1.91	1.94
OT	00:48.210	25.11	25.11
	00:50.120	1.93	1.95
		25.11	85

- How to set?
1. Preview: Click any dashboard to display the detail.
 2. Dashboard Playlist: Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
 3. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

All Dashboards

4. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

0.0.1 beta 2

Configs



Default




Default

Configuration

Dashboard

Paddles

Dashboard Playlist



Preview



How to set?

1. Preview: Click any dashboard to display the detail.
2. Dashboard Playlist: Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
3. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

All Dashboards



Reset

Save As

Save to Flash

PW1

0.0.1 beta 2

Configs

Default

V Paddles Settings

Dashboard Playlist

Preview

00:49.030		5	+1.01	
P02	080.0°		MAP	1
LAP 7			MODE	5
FL 7.0			DIFF	75
F 46.0			BIAS	60
		240	1.91	1.94
			25.11	25.11
DRS			1.93	1.95
			25.11	85
		00:48.210		
		00:50.120		

How to set?

All Dashboards

1. Click on "Paddles" in the menu bar to enter the paddles settings interface.



0.0.1 beta 2

Configs



Default



Dashboard Playlist



Preview

00:49.030	5	+1.01
P02 080.0°		MAP 1
LAP 7		MODE 5
FL 7.0		DIFF 75
F 46.0	240	BIAS 60
DRS		1.91 1.94
OT	00:48.210	25.11 25.11
	00:50.120	1.93 1.95
		25.11 85

How to set?

1. Preview: Click any dashboard to display the detail.
2. Dashboard Playlist: Click and drag the dashboard from below into the "Dashboard Playlist" to complete the setup.
3. Delete Dashboard: Click the "delete" icon to delete dashboard in "Dashboard Playlist".

All Dashboards




Reset

Save As

Save to Flash

⬇ PW1



0.0.2 beta 1

Configs

Default

2. The section below the page is for paddle calibration. This product features a design of interchangeable single/dual clutch, and the software automatically identifies whether it is a single or dual clutch.

Clutch Calibration

Single Clutch MIN 0% MAX

Clutch Input 0%

Default

Configuration

Dashboard

Paddles

PW1



0.0.2 beta 1

Configs

Default

When using a dual clutch, the "Clutch Input" takes the maximum value from both the left and right clutches as the actual input, and the clutch engagement point can be set.

Clutch Calibration

Left MIN 0% MAX

Right MIN 0% MAX

Clutch Input Set Bite Point

35% 0%

Reset

Save As

Save to Flash

Default



0.0.2 beta 1

Configs



Default

3. Calibrate the left and right clutch paddles separately:
Click "MIN" to calibrate the minimum value when the paddle is completely released.
Click "MAX" to calibrate the maximum value when the paddle is fully pressed.

Clutch Calibration

Single Clutch MIN 0% MAX


Single Clutch

Clutch Input

Left	MIN	0%	MAX
Right	MIN	0%	MAX

Dual Clutch

4. Clutch Bite Point Settings for Dual Clutch Module:
Click to turn on the "Bite Point" to adjust the clutch bite point. Drag the purple slider located below the "Clutch Input" display section to adjust the bite point.
(Note: Adjustments to the clutch bite point will only be visible after clicking "Save to Flash".)





PW1

Default

Configuration

Dashboard

Paddles



0.0.2 beta 1

Configs



Default



VI Firmware Update



Clutch Calibration

Single Clutch

MIN

0%

MAX

Clutch Input

0%

Reset

Save As

Save to Flash



43/51



1. Visit www.conspit.com to download the firmware for the corresponding product;
2. Enter the detailed settings pages and click the "↓" symbol in the top left corner to update.



0.0.2 beta 1

Current Firmware Version Display

Configs



Default



Clutch Calibration

Single Clutch

MIN

0%

MAX


Clutch Input

0%

Reset

Save As

Save to Flash



Firmware Update

Select your local firmware file and click 'Confirm'.



Cancel


Confirm

3. Click the ">" button on the right side of the pop-up window to select the firmware you have downloaded for the corresponding product.

Reset

Save As

Save to Flash



4. Then click "Confirm" to update the firmware.

* Note:
If the progress bar gets stuck, please unplug and replug the USB cable and try again.

VII One-Click Game Configuration



PW1

Default

Configuration

Dashboard

Paddles



0.0.2 beta 1

Configs



Default



Clutch Calibration

Single Clutch

MIN

0%

MAX

Clutch Input

0%

Reset

Save As

Save to Flash

1. Click to enter the Homepage.

Connected Devices

PW1

CONSPIT

One-Click Game Configuration

Then click this button to configure.

SIMULATION SEAT ULTIMATE
EXPERIENCE

GT-Lite



Plugins



Overlay

Conspit Link 2.0

beta v1.0.7

Language

English

Software Update

v1.0.7

Version Check

Exit Options

Exit

Game Setting

One-Click Game Configuration

Start on Boot



UDP Port Forwarding

20778

Then click this button to configure.

2. You can also click on the "Settings" icon in the bottom left corner.




VIII Games' Telemetry List

Games	Settings
Assetto Corsa	No need to set up
Assetto Corsa Competizione	No need to set up
iRacing	No need to set up
F1 Series	Enter the game, modify the settings, enable UDP, set the port to 20777. Do not enable broadcast mode.
Automobilista 2	No need to set up
Race Room	No need to set up
rFactor 2	One-click configuration is required within Conspit Link 2.0. Enable telemetry plugin in the game settings.
Le Mans Ultimate	One-click configuration is required within Conspit Link 2.0
Dirt Rally 2.0	One-click configuration is required within Conspit Link 2.0
Forza Horizon 5	Enter the game, modify the settings, enable UDP, set the port to 20777.



Connected Devices

 PW1


Thanks for Watching!



One-Click Game Configuration

SIMULATION SEAT ULTIMATE
EXPERIENCE


GT-Lite



Plugins



Overlay

 If you have any questions, please come back anytime.